2019-2024 Ram 3500 - Wiper Blade Replacement

2019-2024 Ram 3500 | Easy | 10-15 minutes | $66 DIY

TOOLS

Clean microfiber cloth Glass cleaner Folded towel (to protect the windshield while blades are off) Step stool (optional, for reaching the tall windshield)

PARTS

Driver wiper blade, 22" Bosch 22A $32.99
Passenger wiper blade, 22" Bosch 22B $32.99

STEPS

1. **Confirm the blade sizes and buy the new blades - Buy two 22-inch blades before you start** - a couple of fitment charts list 24-inch blades for this generation, but the majority of catalogs agree on 22 inches, so measure your old blades to be sure.
2. **Park the wipers and lift the driver-side arm - Turn the truck off and make sure the** wipers are parked at the base of the windshield. The tall windshield means you may need to stand on the door sill or a sturdy step to reach comfortably.
3. **Remove the old driver-side blade (J-hook) - Lift the driver-side arm, find the release** tab where the blade clips into the hook, press it, and slide the old blade down and out of the hook. Set the old blade aside to compare lengths with the new one.
4. **Prep the new driver-side blade - Lay the new 22-inch blade beside the old one to confirm** the length matches. Keep the protective cover on the rubber edge until the blade is mounted. Check that the J-hook adapter on the new blade is the right type for the truck's arm.
5. **Install the new driver-side blade and check the lock - Thread the arm's hook through the** new blade's adapter and slide the blade up until it clicks firmly into place. Give the blade a firm tug to confirm the lock - it should not slide or wobble.
6. **Do the passenger side (no rear wiper on a pickup) - Repeat the same J-hook release and** install on the passenger side with the second 22-inch blade. The Ram 3500 is a pickup, so there is no rear wiper to replace - the two fronts complete the job.
7. **Test with washer fluid and inspect the wipe - Start the truck, spray washer fluid, and** run the wipers on low and high speed. If either blade chatters, pop it off and re-seat the adapter until you get a solid click.

TORQUE

ezcarfix.com