# 2014-2024 Ram ProMaster - Wiper Blade Replacement



2014-2024 Ram ProMaster | Easy | 10-15 minutes | $66 DIY

**TOOLS**

Sturdy step stool or stand on the door sill (the van's windshield is tall) Clean rag or paper towel

**PARTS**

Driver wiper blade, 26" Bosch 26A $32.99
Passenger wiper blade, 22" Bosch 22B $32.99

## STEPS

1. **Confirm your sizes and buy the blades - The 2014-2024 Ram ProMaster takes a 26-inch blade** on the driver's side and a 22-inch blade on the passenger's side - this holds for the 1500, 2500, and 3500. Measure your old blades before buying: a 26 on the passenger side hangs past...
2. **Lift both arms off the glass - The ProMaster needs no wiper service position - the blades** park on the glass with clear access, so just pull each arm straight up off the windshield. The arms are long and the van is tall, so you may need to stand on the door sill or a s...
3. **Remove the driver's-side blade - Press the tab and slide the blade downward out of the** hook's curve, guiding the long 26-inch blade with your free hand so it doesn't swing into the glass.
4. **Prep the new driver's-side blade - Open the new 26-inch blade and pull off the plastic** protector covering the rubber edge - skipping this leaves instant streaks and is the most common install mistake. Check that the J-hook adapter is pre-fitted and snapped firmly into the...
5. **Install the new blade and check the lock - Slide the new 26-inch blade up into the J-hook** until the locking tab snaps over the hook with a solid click. Pull the blade firmly along the arm's direction - it must not slide or rock at all. If there's any play, the tab missed; pull it...
6. **Do the passenger side with the 22-inch blade - Gently lower the driver's arm back onto** the glass, then repeat the swap on the passenger side with the 22-inch blade - press the tab, slide the old blade off, strip the new blade's protector, and click it on. The 4-inch difference is eas...
7. **Test both blades with the washer fluid - Start the van and run the wipers through one** full sweep, watching the big windshield for missed bands, chatter, or the two blades clashing near the center. Pull the stalk to spray washer fluid across the glass and confirm the 26-inch drive...

**TORQUE**

ezcarfix.com