2022-2024 Rivian R1T - Cabin Air Filter Replacement

2022-2024 Rivian R1T | Easy | 15-20 minutes | $28 DIY

TOOLS

Phillips screwdriver Plastic trim tool
Magnetic parts tray Flashlight or headlamp

PARTS

Cabin air filter for 2022-2024 Rivian R1T; verify arrows, size, and VIN/trim fitment
$28.00

STEPS

1. **Prep: the R1T’s glove box is screwed in, not squeezed - Behind the glove box - but the** R1T has no squeeze-to-release stops; it’s screwed in with eight screws (three underneath, five inside) plus a side panel that comes off first. Power the vehicle down, empty the glove box, and grab a headlam...
2. **Remove the eight screws and the side panel - Remove the three screws underneath the glove** box, then the five inside - use a magnetic parts tray, since these screws roll under the seats. Pull the side trim panel off with a plastic trim tool, which won’t mar the finish.
3. **Drop the glove box and unhook its wiring - Ease the glove compartment out of the dash,** but unhook its wiring before pulling it far - fighting the wiring while the box hangs is how pins get bent. Set the box on the passenger seat; the filter cover door is now exposed.
4. **Open the filter door and photograph the arrow - Remove the filter cover door and** photograph the filter’s face - the airflow arrow molded into its frame. That arrow is the only orientation guide; copy it exactly. The filter sits in a deep slot, so the photo shows how far in it was seat...
5. **Swap the filter, arrow matched to the old one - Pull the old filter straight out by its** frame and compare it with the replacement. Clear debris from the slot, then slide the new filter in with its arrow matching the old one’s (typically down) until the frame sits flush - half-seated f...
6. **Reinstall the box, all eight screws, and the side panel - Refit the filter door until it** latches, lift the box back - wiring plugs first so nothing gets pinched. Reinstall eight screws (three underneath, five inside) and snap the panel on. Open and close the box twice; wobbling means a missed s...
7. **Power up and check the fan - Power the R1T up and run the HVAC at full speed through** dash, floor, and defrost. Listen for even, quiet airflow - whistling means the filter isn’t seated; rattling means debris or a loose screw. Inspect the filter yearly, sooner if you...

TORQUE

ezcarfix.com